

MARKERS

BEEKLEY S-SPOT® 607 FLORALS®

S-SPOT® CT Simulation Marker 607 Florals®

Help define architectural distortion at the biopsy site by delineating the exact location of incision.

Ref: 607, (QTY: 363cm cut to measure roll/box)


- *33mm diameter radiopaque line*
- *burnout-resistant brighter image*
- *for marking scars and field borders*

[Read More](#)

CODE BEEK607

Category: [Markers](#)

Tag: [S-SPOT® CT Simulation Marker](#)





BEEKLEY S-SPOT® 607 FLORALS®

S-SPOT® CT Simulation Marker 607 Florals®

Help define architectural distortion at the biopsy site by delineating the exact location of incision.

Ref: 607, (QTY: 363cm cut to measure roll/box)


- 33mm diameter radiopaque line
- burnout-resistant brighter image
- for marking scars and field borders

[Read More](#)

CODE C-BEEK607

Categories: [Markers](#), [Skin Markers](#)

Tag: [S-SPOT® CT Simulation Marker](#)



SKIN MARKERS

BEEKLEY S-SPOT® 607 FLORALS®

S-SPOT® CT Simulation Marker 607 Florals®

Help define architectural distortion at the biopsy site by delineating the exact location of incision.

Ref: 607, (QTY: 363cm cut to measure roll/box)

- *33mm diameter radiopaque line*
- *burnout-resistant brighter image*
- *for marking scars and field borders*

[Read More](#)

CODE C-BEEK607

Categories: [Markers](#), [Skin Markers](#)

Tag: [S-SPOT® CT Simulation Marker](#)

